


Application Note

Installation of LC QuickPort Adapters in angled faceplates

LC QuickPort Adapters provide mating capability for fiber optic cables with LC connectors in all QuickPort compatible faceplates, patch panels, adapter plates and Multimedia Outlet System housings.

LC connectors have a locking tab release located on the top (key up) of each connector.



These release tabs are positioned “key-up” in QuickPort adapters. In certain angled QuickPort faceplates and inserts, the QuickPort jack is installed in the upside down position. In these applications, when the LC adapter is installed the release tabs are inaccessible.


Application Note ID:
NS-AN-15-0018

Date:
05/28/2024

Product Line:
QuickPort Connectors

Part Numbers Affected:

41086-ML*
41086-LL*
41086-SL*
41294-2Q*
41081 series angled faceplates
42081 series angled faceplates
43081 series angled faceplates
LI137-AFW



This applications note provides instruction on how to re-position the LC coupler in the adapter bezel to allow for release tab accessibility.

USA
Network Solutions Headquarters
+1 (800) 722 2082
infoUSA@leviton.com

Leviton Berk-Tek Cable: +1 (800) 237 5835
berktek.info@leviton.com

Asia Pacific
+852 3620 2602
infoAPAC@leviton.com

NETWORK SOLUTIONS PRODUCTS ARE AVAILABLE WORLDWIDE IN OVER 100 COUNTRIES. VISIT US ONLINE AT LEVITON.COM/NS TO LEARN MORE.

Canada
+1 (800) 461 2002
infoCanada@leviton.com

infoEurope@leviton.com

Europe
+44 (0) 1592 772124
infoEurope@leviton.com

Latin America
MX: +52 (55) 2128 6286
LATAM: +52 (55) 2333 5963
infoLATAM@leviton.com

Middle East & Africa
+971 (4) 247 9800
infoMEA@leviton.com

To rotate an LC coupler in a QuickPort Adapter:

1. Using a small flat bladed screwdriver, gently press down on the plastic spring tab on one side of the adapter bezel and pull the coupler slightly forward keeping constant pressure.
2. While maintaining pressure, repeat the step to the plastic spring tab on the opposite side of the adapter bezel.
3. The coupler should now pull forward out of the adapter bezel.
4. Rotate the LC coupler 180 degrees ("key-down") and re-insert into the adapter bezel until the plastic spring tabs re-engage in the opening.

